A/C*22	4
ABS20	)1
ACCESSORY mode138	8
Air conditioning filter43	4
Air conditioning system	
Air conditioning filter43	4
Automatic air conditioning	
system22	4
Airbags	
Airbag operating conditions9	9
Airbag precautions for your	
child10	3
Airbag warning light470	C
Curtain shield airbag operating	
conditions9'	9
Curtain shield airbag	
precautions10	3
Front passenger occupant	
classification system10	8
General airbag precautions 10	3
Locations of airbags9	6
Modification and disposal of	
airbags10	7
Proper driving posture94, 10	3
Side airbag operating	
conditions91	9
Side airbag precautions10	3
SRS airbags9	6
Alarm9	0
Antenna*24	2
Anti-lock brake system20	
Armrest35	6
Ashtrays35	
Assist grips360	
Audio input*27	9
Audio system*	
A	$^{\circ}$

Audio input	279
AUX port	279
Bluetooth <sup>®</sup> audio	284
CD player/changer	245
iPod	260
MP3/WMA disc	252
Optimal use	277
Portable music player	279
Radio	237
Steering wheel audio switch	281
USB memory	268
USB port260	, 268
Automatic air conditioning	
system*	224
Automatic headlight leveling	
system	169
Automatic light control system	166
Automatic transmission	
Automatic transmission	142
If the shift lever cannot be	
shifted from P	503
M mode	147
AUX port*	279
Auxiliary box	344
Back-up lights	
Wattage	528
Battery	
Checking	413
If the vehicle has a discharged	
battery	508
Preparing and checking	
before winter	218
Bluetooth <sup>®</sup> audio*	
Bluetooth® phone*	
Bottle holders	

Brake	
Fluid	411
Parking brake	152
Brake assist	201
Care	
Exterior	384
Interior	388
Seat belts	389
Cargo capacity	214
Cargo hooks	362
CD changer*	245
CD player*	245
Chains	218
Child restraint system	
Booster seats, definition	113
Booster seats, installation	119
Convertible seats, definition	113
Convertible seats, installation	119
Front passenger occupant	
classification system	108
Infant seats, definition	113
Infant seats, installation	119
Installing CRS with lower	
anchorages	118
Installing CRS with seat belts	119
Installing CRS with top straps	123
Child safety	
Airbag precautions	103
Battery precautions415	5, 510
Child restraint system	
Child-protectors	47
How your child should wear	
the seat belt	68

Installing child restraints	117
Moon roof precautions	
Power window lock switch	
Power window precautions	
Removed electronic key batter	
precautions	
Seat belt comfort guide	
Seat belt extender precautions.	70
Seat belt precautions	
Seat heater precautions	
Trunk precautions	
Child-protectors	
Cigarette lighter	352
Cleaning	
Exterior	.384
Interior	.388
Seat belts	.389
Clock	347
Coat hooks	359
Compass	371
Condenser	411
Console box	340
Cooling system	
Engine overheating	511
Cornering assist sensors	195
Cruise control	
Cruise control	177
Dynamic radar cruise control	181
Cup holders	342
Curtain shield airbags	96
Customizable features	544

 $<sup>\</sup>mbox{\ensuremath{^{\star}}}\mbox{:}$  For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

D	Daytime running light system168	If the electronic key does not
	Defogger*	operate properly505
	Rear window232	If the engine will not start502
	Side mirrors232	If the shift lever cannot be
	Dimension518	shifted from P503
	Dinghy towing221	If the vehicle has a discharged
	Display	battery508
	Dynamic radar cruise control181	If the warning buzzer sounds 469
	Satellite switch mode348	If the warning light turns on469
	Trip information162	If you have a flat tire493
	Warning message479	lf you lose your keys504
	Do-it-yourself maintenance397	If you think something is
	Door courtesy lights	wrong467
	Door courtesy lights334	If your vehicle becomes stuck514
	Wattage528	If your vehicle has to be
	Door pockets344	stopped in an emergency515
	Doors	If your vehicle needs to be
	Door lock32, 43, 46	towed461
	Door windows78	If your vehicle overheats511
	Side mirrors76	Engine
	Driver's seat belt reminder light 472	ACCESSORY mode138
	Driving	Compartment403
	Correct posture94	Engine switch138
	Procedures128	Hood400
	Driving position memory56	How to start the engine138
		ldentification number519
Ε	Electric power steering201	If the engine will not start502
	Electronic key	Ignition switch138
	If the electronic key does not	Overheating51
	operate properly505	Engine compartment cover404
	Emergency flashers	Engine coolant
	Switch460	Capacity 523
	Emergency, in case of	Checking409
	If a warning message is	Preparing and checking
	displayed479	before winter218
	aispiayea 77	

Engine coolant temperature		Fuel	
gauge	154	Capacity	521
Engine immobilizer system	88	Fuel gauge	154
Engine oil		Fuel pump shut off system	468
Capacity	522	Gas station information	584
Checking	406	Information	529
Preparing and checking		Refueling	85
before winter	218	Fuel door	85
EPS	201	Fuel filler door	85
Event data recorder	22	Fuel pump shut off system	468
		Fuses	438
First-aid kit storage belt	362		
Floor mat		Garage door opener	365
Fluid	ļ	Gas station information	
Brake	411	Gauges	154
Washer	416	Glove box	339
Fog lights		Glove box light	339
Switch	170		
Wattage	528	Hands-free system for mobile	
Footwell lights	334	phone*	303
Front fog lights		Hazard lights	
Switch	170	Switch	460
Wattage	528	Head restraints	
Front passenger occupant		Adjusting	62
classification system	108	Headlight aim	
Front passenger's seat belt		Headlight cleaner	
reminder light	472	Headlights	
Front seats		Discharge headlight	
Adjustment	55	precautions	458
Driving position memory	56	Replacing light bulbs	
Seat position memory	60	Switch	
Front turn signal lights		Wattage	528
Switch	151		
Wattage	528		

<sup>\*:</sup> For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

Heaters		K Keyless entry	43
Seat heaters	354	Keys	
Side mirrors	232	Electronic key	28
Hill-start assist control	201	Engine switch	138
Hood	400	If the electronic key does not	
Hooks		operate properly	505
Cargo	362	If you lose your keys	
Coat	359	Key number	28
Shopping bag	362	Keyless entry	43
Horn	153	Keys	28
		Mechanical key	29
1 I/M test	396	Wireless remote control key.	43
Identification			
Engine	519	L Lexus Enform*	
Vehicle	519	Light bulbs	
Ignition switch	138	Replacing	454
Illuminated entry system	334	Wattage	528
Indicator lights	158	Lights	
Initialization		Door courtesy lights	334
Items to initialize	549	Emergency flasher switch	460
Inside rear view mirror	74	Fog light switch	17C
Interior lights		Hazard light switch	460
Interior lights	334	Headlights switch	166
Switch	336	Interior light switch	336
Wattage	528	Outer foot lights	334
		Personal light switch	336
J Jack		Replacing light bulbs	454
Positioning a floor jack	401	Shift lever light	334
Vehicle-equipped jack		Turn signal lever	151
Jack handle		Vanity lights	346
		Wattage	528
		Load capacity	217

М	Maintenance	Outside rear view mirrors	
	Do-it-yourself maintenance 397	Adjusting and folding	76
	General maintenance393	Mirror position memory	56
	Maintenance data 518	Outside temperature display	162
	Maintenance requirements391	Overhead console	341
	Meter	Overhead courtesy lights	
	Instrument panel light control156	Overhead courtesy lights	334
	Meters154	Wattage	528
	Micro dust and pollen filter* 228	Overheating, Engine	511
	Mirrors		
	Inside rear view mirror74	Parking assist sensors*	195
	Side mirror heater232	Parking brake	
	Side mirrors76	Parking lights	
	Vanity mirrors346	Replacing light bulbs	454
	Moon roof81	Switch	
	MP3 disc*252	Wattage	
	Multi-information display161	PCS	
		Personal lights	
Ν	Noise from under vehicle19	Switch	336
		Power outlet	353
0	Odometer154	Power windows	78
	Oil	Pre-collision system	207
	Engine oil406		
	Opener		
	Fuel filler door85		
	Hood400		
	Trunk51		
	Outer foot lights		
	Outer foot lights334		
	_		
	Wattage528		

<sup>\*:</sup> For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

R	Radar cruise control181	Seat heaters	354
	Radiator411	Seat position memory	60
	Radio*237	Seating capacity	217
	RDS*239	Seats	
	Rear turn signal lights	Adjustment	55
	Replacing light bulbs454	Adjustment precautions	55
	Wattage528	Child seats/child restraint	
	Rear view mirror	system installation	117
	Compass371	Cleaning	
	Rear window defogger*232	Driver's seat position memory	
	Replacing	Front passenger seat position	
	Electronic key battery436	memory	60
	Fuses438	Head restraints	62
	Light bulbs454	Properly sitting in the seat	94
	Reporting safety defects for	Seat heaters	
	U.S. owners552	Service reminder indicators	158
	Reset the maintenance data392	Shift lever	
		If the shift lever cannot be	
S	Safety connect	shifted from P	503
	Seat belts	Transmission	142
	Adjusting the seat belt66	Shift lever light	334
	Automatic locking retractor	Shift lock system	503
	Child restraint system	Shopping bag hooks	362
	installation117	Side airbags	96
	Cleaning and maintaining	Side marker lights	
	the seat belts389	Switch	166
	Emergency locking retractor 67	Side mirrors	
	How to wear your seat belt65	Adjusting and folding	76
	How your child should wear	Mirror position memory	56
	the seat belt68	Smart access system with	
	Pregnant women,	push-button start	
	proper seat belt use67	Entry function	32
	Reminder light472	Starting the engine	
	Seat belt extenders68	"SOS" button	
	Seat belt pretensioners66		
	1	1	

Spare tire
Inflation pressure428
Storage location493
Spark plug524
Specifications518
Speedometer154
Steering wheel
Adjustment72
Audio switches281
Steering wheel position
memory56
Storage feature338
Stuck
If your vehicle becomes stuck514
If your vehicle becomes stuck514 Sun visors345
· ·
Sun visors

Power door lock switch	40
Power window switch	78
Satellite switches	348
SNOW switch	144
Transmission shift	
switches	145, 147
VSC off switch	202
Window lock switch	78
Wiper and washer switch	172
Tachometer	154
Tail lights	
Switch	166
Talk switch*	308
Telephone switch*	308
Theft deterrent system	
Alarm	90
Engine immobilizer system.	88
Theft prevention labels	93
Tire inflation pressure	428
Tire information	
Glossary	537
Size	534
Tire identification number	534
Uniform tire quality grading	535

<sup>\*:</sup> For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

Tires			Turn signal lights	
Chains	218		Replacing light bulbs	454
Checking	417		Switch	151
If you have a flat tire	493		Wattage	528
Inflation pressure	428			
Inflation pressure sensor	417	U	USB port*2	260. 268
Information	532			,
Replacing	493	V	Vanity lights	
Rotating tires	417		Vanity lights	346
Size	527		Wattage	
Snow tires	218		Vanity mirrors	
Tools	493		VDIM	
Total load capacity	217		Vehicle data recordings	
Towing			Vehicle dynamics integrated	
Dinghy towing	221		management	201
Emergency towing	461		Vehicle identification number	
Trailer towing	220		Vehicle stability control	
TRAC	201		Voice command switch	
Traction control	201		VSC	
Transmission shift switches	.145, 147		V 3C	201
Trip meter	154	W	\A/ · I	
Trunk		٧٧	Warning buzzers	4/0
Extending trunk space	357		Brake system	
Opener	51		Open door	
Trunk light			Seat belt reminder	4/2
Trunk light	52			
Wattage	528			

### Warning lights

Anti-lock brake system4	70
Brake assist system4	70
Brake system4	69
Charging system4	70
Electric power steering system	
warning light4	70
Low fuel level4	72
Malfunction indicator lamp4	70
Master warning light4	72
Open door4	72
Pre-collision system4	
Pretensioners4	70
Seat belt reminder light4	72
SRS airbags4	70
Tire pressure warning	
light 4	72

#### Warning messages

Automatic transmission	
fluid483	3
Dynamic radar	
cruise control481, 483	3
Engine oil level	3
Engine oil maintenance483	3
Engine oil pressure480	)
Engine oil temperature480	)
Headlight48	1
Hood483	3
Intuitive parking assist481, 483	3
Moon roof483	3
Open door483	3
Parking brake483	3
Pre-collision system481, 483	3
Smart access system with	
push-button start489	)
Steering lock48	1
Trunk483	3
Washer fluid483	3
Washer	
Checking416	)
Preparing and checking	
before winter218	3
Switch172	)
Washing and waxing384	ļ

<sup>\*:</sup> For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

Weight	
Cargo capacity	214
Load limits	217
Weight	518
Wheels	432
Window glasses	78
Window lock switch	78
Windows	
Power windows	78
Rear window defogger	232
Washer	172
Windshield wipers	172
Windshield wiper de-icer	233
Wireless remote control key	
Replacing the battery	436
WMA disc*	

<sup>\*:</sup> For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".